

# VINCENT SHEPPARD



## DAVID COLLECTION

PRODUCT DATA SHEET

# DAVID COLLECTION



DAVID DINING ARMCHAIR



DAVID LOUNGE CHAIR



DAVID LOUNGE SOFA



DAVID SIDE TABLE



DAVID COFFEE TABLE



DAVID DINING TABLE




## DAVID

<b>frame</b>	solid teak	
<b>frame finish</b>	aged teak (stained & brushed)	
<b>rope</b>	polypropylene	
<b>rope color</b>	grège	
<b>top/finish</b>	ceramic	flint
<b>glides</b>	black nylon	

## COLOURS



## DIMENSIONS






## CUSHION

<b>foam</b>	dining chair: 4 cm quick dry foam lounges: 10 cm quick dry foam
<b>removable</b>	yes
<b>fabrics</b>	see fabric data sheet for more info

## PROTECTIVE COVERS

We recommend using protective covers only on **dry** teak furniture.

<b>dining chair</b>	PC001
<b>lounge chair</b>	PC002
<b>lounge sofa</b>	PC003



## IN THIS COLLECTION

DAVID	ITEM CODE	FINISH	PACKAGE DIMENSION (cm/inch)		CBM (m <sup>3</sup> /ft <sup>3</sup> )	WEIGHT (kg/lb)	
dining chair	GD091W092	aged teak	85 x 61 x 66	34 x 24 x 26	0,34 12	12	27
dining table 210	GT056W092K001	aged teak/flint	46 x 178 x 80 20 x 215 x 110	18 x 70 x 31.5 8 x 85 x 43	2,43 85.8 0,47 16.6	93,5 206 68 149	
dining table 280	GT057W092K001	aged teak/flint	46 x 178 x 80 20 x 285 x 110	18 x 70 x 31.5 8 x 112.2 x 43	2,43 85.8 0,63 22.5	93,5 206 68 149	
lounge chair	GC085W092	aged teak	81 x 80 x 90	32 x 31.5 x 35.5	0,58 20.5	25	55
lounge sofa	GC086W092	aged teak	78 x 168 x 90	30.7 x 66 x 35.4	1,18 41.7	28	61
coffee table	GT054W092K001	aged teak/flint	31 x 134 x 50	12 x 52.8 x 19.7	0,21 7.5	23,3	51.5
side table	GT055W092K001	aged teak/flint	44 x 46 x 46	17.3 x 18 x 18	0,09 3.2	12,5	28

## **MAINTENANCE AND CARE**

---

### **STAINED TEAK**

#### **FOR DAILY CARE**

Use a moist towel or sponge with a mild solution of water and natural, non-aggressive soap.

#### **FOR STUBBORN STAINS**

If your furniture is stained, consider one of the following options:

- **Grease spots have appeared on the furniture**  
This is a natural feature of the wood and grease spots should gradually disappear after being exposed to sunlight. However, should you wish to remove these blemishes, we recommend using a degreasing agent and gentle scrubbing with a brush. Rinse off with clean water.
- **The furniture has developed mildew spots or black blemishes**  
This is usually the result of rainwater or sometimes sap dripping from the leaves of trees onto the wood leaving dark marks and spots. Ideally, we recommend the furniture is not placed under trees. However, these marks can be removed by lightly sanding with fine sandpaper.
- **You spilled wine or something else leaving persistent stains**  
For wine and other stains, we recommend using a weak solution of bleach and water combined with a dishwashing agent to wipe the area clean.

### **CERAMIC**

If you're looking for a material which requires little to no maintenance, yet offers maximum resistance, you would do well to involve ceramic. The material preserves the natural look of stone and offers top of the chart convenience. Cleaning the table with water and mild soap will do the trick!

### **POLYPROPYLENE ROPE**

Another material used for our all-weather furniture, is rope. Our rope is made of polypropylene fibres or acrylic. Just like our other synthetic materials, the rope is designed to withstand any weather condition and can be left outside all year long.

For maintaining your rope furniture, we recommend using a fabric and upholstery protector to give optimal stain resistance.

To clean spots on the rope, we suggest applying a mist of soapy water with a spray bottle and then work the solution into the rope with a soft cloth by patting or rubbing lightly. Rinse the solution thoroughly and then blot excess moisture from the rope using a soft cloth and allow air-drying.

Never use a high-pressure hose on acrylic rope.