


VINCENT
SHEPPARD



REMI COLLECTION

PRODUCT DATA SHEET



REMI

frame	teak
frame finish	untreated teak
seat	polypropylene rope
seat colours	fossil grey, dune white
glides	white nylon

CUSHION

foam	dining chair	2 cm polyether foam
removable	yes	
fabrics	see fabric data sheet for more info	

FRAME FINISH



UNTREATED TEAK

SEAT COLOURS



FOSSIL GREY



DUNE WHITE


PROTECTIVE COVERS

We recommend using protective covers only on **dry teak furniture**.

dining chair	PC001
---------------------	-------

DIMENSIONS

DINING CHAIR TEAK BASE



VARIANTS

DINING CHAIR	ITEM CODE	FINISH	PACKAGE DIMENSION (cm/inch)		CBM (m³/ft³)	WEIGHT (kg/lb)
Teak base	GD1830W002S033	fossil grey	61 x 90 x 65	24 x 35.5 x 25.6	0,36 12.7	12,5 27.56
	GD1830W002S045	dune white				

MAINTENANCE AND CARE

TEAK

Daily care

Use a moist towel or sponge with a mild solution of water and natural, non-aggressive soap.

Stubborn stains

If your furniture is stained, consider one of the following options:

- **Grease spots have appeared on the furniture**
This is a natural feature of the wood and grease spots should gradually disappear after being exposed to sunlight. However, should you wish to remove these blemishes, we recommend using a degreasing agent and gentle scrubbing with a brush. Rinse off with clean water.
- **The furniture has developed mildew spots or black blemishes**
This is usually the result of rainwater or sometimes sap dripping from the leaves of trees onto the wood leaving dark marks and spots. Ideally, we recommend the furniture is not placed under trees. However, these marks can be removed by lightly sanding with fine sandpaper.
- **You spilled wine or something else leaving persistent stains**
For wine and other stains, we recommend using a weak solution of bleach and water combined with a dishwashing agent to wipe the area clean.